

Cleaning Solutions and Rowmark Products

Rowmark Product	Furniture Polish (Pledge®)	Rubbing Alcohol	All Purpose Cleaner (Formula 409®)	Dish Soap (non citrus)	Window Cleaner	Bleach Cleaner (Clorox®)	Citrus Cleaner (Goo Gone®)	Novice Scratch Remover	Pinesol® Cleaner	Lysol® Spray	Dow® Bathroom & Tile Cleaner	Lysol® Basin, Tub & Tile	Lacquer Thinner	Lighter Fluid
ADA Alternative®	😊	😞	😊	😊	😊	😊	😊	😊	😊	😞	😞	😞	😊	😞
ColorCast Acrylics	😊	😞	😊	😊	😊	😊	😊	😊	😊	😞	😞	😞	😊	😞
Earhtones	😊	😞	😊	😊	😊	😊	😊	😊	😊	😞	😞	😞	😊	😞
FlexiBrass® & FlexiColor®*	😊	😞	😊	😊	😊	😊	😊	😊	😊	😞	😞	😞	😊	😞
Granites Deluxe™	😊	😞	😊	😊	😊	😊	😊	😊	😊	😞	😞	😞	😊	😞
Heavy Weights	😊	😊	😊	😊	😊	😊	😊	😊	😊	😞	😞	😞	😊	😞
Lacquers	😊	😞	😊	😊	😊	😊	😊	😊	😊	😞	😞	😞	😊	😞
LaserLIGHTS	😊	😞	😊	😊	😊	😊	😊	😊	😊	😞	😞	😞	😊	😞
LASERmag	😊	😞	😊	😊	😊	😊	😊	😊	😊	😞	😞	😞	😊	😞
LaserMark®*	😊	😞	😊	😊	😊	😊	😊	😊	😊	😞	😞	😞	😊	😞
LaserMax®*	😊	😊	😊	😊	😊	😊	😊	😊	😊	😞	😞	😊	😞	😊
Mattes	😊	😞	😊	😊	😊	😊	😊	😊	😊	😞	😞	😞	😊	😞
NoMark® Plus*	😊	😞	😊	😊	😊	😊	😊	😊	😊	😞	😞	😞	😊	😞
Outdoor Weatherable Metals	😊	😞	😊	😊	😊	😊	😊	😊	😊	😞	😞	😊	😞	😊
Reverse LaserMark®*	😊	😞	😊	😊	😊	😊	😊	😊	😊	😞	😞	😞	😊	😞
Satins	😊	😞	😊	😊	😊	😊	😊	😊	😊	😞	😞	😊	😞	😊
Silks	😊	😊	😊	😊	😊	😊	😊	😊	😊	😞	😞	😊	😞	😊
Slickers	😊	😞	😊	😊	😊	😊	😊	😊	😊	😞	😞	😊	😞	😊
Standard Metals*	😊	😞	😊	😊	😊	😊	😊	😊	😊	😞	😞	😞	😊	😞
Textures	😊	😞	😊	😊	😊	😊	😊	😊	😊	😞	😞	😊	😞	😊
Ultra-Mattes Front Engravable	😊	😞	😊	😊	😊	😊	😊	😊	😊	😞	😞	😊	😞	😊
Ultra-Mattes Reverse Engravable	😊	😞	😊	😊	😊	😊	😊	😊	😊	😞	😞	😊	😞	😊

-  safe to use
-  use sparingly
-  not recommended

* Metallic foils are metal based and are prone to oxidation in high humidity environments.

Tips for cleaning Rowmark sheet products:

1. As a general rule, *Rowmark recommends using mild soap and water whenever possible* .
2. Test a piece of scrap or small area of the material before cleaning entire piece.
3. Use only soft cloths or sponges for cleaning. Do not use Brillo®/S.O.S.® pads or steel wool.
4. Use a Q-Tip® to clean small areas.
5. Rinse with warm water.
6. Ultrasonic cleaning is NOT RECOMMENDED for *any* Rowmark product.
7. To remove dust from engraved areas, try compressed air before any solvent cleaner.
8. Cleaners with abrasives, such as Comet® brand cleaner, are not recommended.